

**Pioneer**

Operating Instructions

– Advanced MCACC PC Display Application Software –



audio/video multi-channel receiver

## About this manual

These are the Operating Instructions for an application which displays on your computer screen the listening room reverberation frequency characteristics, the speakers' group delay characteristics and the MCACC parameters measured by the Advanced MCACC function of your receiver.

It explains everything you need to know to use the application, from loading measurement data to displaying measurement results and troubleshooting. You will need to operate the receiver to use this application, so please refer also to the Operating Instructions supplied with the receiver.

### **Important**

**The explanations concerning the "Group Delay" functions ("group delay characteristics of the speakers", etc.) included in these operating instructions only apply for receivers supporting the Full Band Phase Control function.**

## About the Advanced MCACC Application

The functions of the Advanced MCACC application are used with the same purpose as the "Reverb View" and "Group Delay" functions of the receiver itself (see the receiver's Operating Instructions), namely to display the reverberation characteristics of the listening environment and the group delay characteristics of the speakers. Using a computer provides cleaner, more easily readable graphs. The application can also be used to display the measurement values stored in the receiver's MCACC memory.

## Requirements for using the application on your PC

- The computer must be a PC functioning with one of the following operating systems: Microsoft® Windows® 7 Home Premium/Ultimate/Professional, Windows® Vista Home Basic/Home Premium/Ultimate SP2 or Windows® XP Professional/Home Edition SP3.
- The monitor must have a display resolution of 1024 x 768 dots (XGA) or greater.
- That the receiver and computer are connected to the network via LAN.

Microsoft®, Windows®, 7, Windows® Vista and Windows® XP are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

## Main features of the application

1. Displays 3D graphs of the reverberation frequency characteristics of your room. You can choose to see these measurements both with and without the equalization performed by this receiver (before and after calibration).
2. Allows you to display 3D graphics of the group delay characteristics of the different speakers. (The values before and after calibration can be displayed.)
3. Allows you to display a list of the Advanced MCACC parameters (the results of measurements).
4. Allows you to view graphs in a number of different formats.
5. Allows you to save the various measured data on the computer.
6. Allows you to make memos about the conditions in your room when you made the measurements, etc.
7. Allows you to print the various graphs and the MCACC measurement values.

**Continue** 

## Things you can accomplish with this application

1. Advanced EQ Setup, which you can do with the receiver (see the receiver's Operating Instructions), allows you to choose the optimum time period for auto EQ setup. You can use this application's reverberation characteristics (Reverb) as a guide in choosing the best time period for your room. For details, see [Deciding the time period for Advanced EQ Setup calibration \(page 15\)](#).
2. Skewed reverb frequency characteristics in your listening room can prevent you from enjoying an accurate sound field. The graphs displayed by this application are a powerful tool because they allow you to check these reverb frequency characteristics at a glance. You can also check the effectiveness of steps that you take to improve the acoustics of your listening room, for example, installing sound absorbent material. For details, see [Checking steps to improve your room's reverb characteristics \(page 17\)](#).
3. The reverb characteristics after calibration can be displayed. This lets you to check the EQ effects of the Advanced MCACC measurements you have made. For details, see [About the display of the reverb characteristics graphs before and after calibration \(page 19\)](#).
4. The Group Delay graphs allow you to check the group delay characteristics before and after calibration. For details, see [Reading the group delay characteristics graph \(Group Delay\) \(page 21\)](#).
5. The MCACC parameter display (Parameters) allows you to display on the computer all the parameters (measurement values) stored in the receiver's MCACC memories. For details, see [Display of the MCACC parameters \(page 22\)](#).

# **Transferring measurement data from the receiver to the computer**

---

To display on the computer the various data measured on the receiver, use AVNavigator to transfer the data from the receiver to the computer.

If MCACC Application is launched automatically after the “Full Auto MCACC” operation has been performed with AVNavigator’s “Wiring Navi” and measurements have been taken, the measurement data has already been transferred to the computer. To recheck the measurement data in this case, proceed to the next section, [Applications Operations \(page 6\)](#).

If “Wiring Navi” has not been performed and you want to transfer the data measured under an environment different from that of “Wiring Navi” to the computer, use the procedure described below.

- 1 Perform the “Full Auto MCACC” operation on the receiver. (See the receiver’s Operating Instructions.)**
- 2 After the “Full Auto MCACC” operation is completed, press the “HOME MENU” button to close the home menu.**  
The measurement data is prepared to be sent at the point that the home menu is closed.
- 3 Launch AVNavigator on the computer.**
- 4 From the AVNavigator menu, select “Settings”, then select the “MCACC Data” tab.**
- 5 Specify the “MCACC Data Storage Folder”.**  
The measurement is saved in the folder specified here. The folder in which the data is saved can be changed by pressing “Change”.
- 6 From the AVNavigator menu, select “MCACC Appli” to launch MCACC Application.**  
When the MCACC application is launched, the “MCACC data” screen appears simultaneously.
- 7 Follow the instructions on the “MCACC data” screen to download the data measured in step 1.**

The data measured in step 1 is transferred to the folder specified in step 4.

Proceed to [Applications Operations \(page 6\)](#) and call out the measurement data from the computer.

**Continue**



### Note

- Do not quit AVNavigator or turn off the receiver's power until data transmission is completed.
- Transmission of measurement data from the receiver to the computer is performed each time MCACC Application is launched with the receiver's power turned on. The measurement data is overwritten unless the "MCACC Data Storage Folder" is changed, so if you do not wish to overwrite the measurement data, change the storage folder at "MCACC Data" under "Settings" before launching MCACC Application.
- The graphs for both before calibration ("Before") and after calibration ("After") can be displayed on the screen displaying the reverberation characteristics graphs after Full Auto MCACC measurements ("Reverb"), but note that the graph displayed for the characteristics after calibration is a prediction of the reverberation characteristics after Full Auto MCACC with the EQ Type : SYMMETRY.

For details, see [About the display of the reverb characteristics graphs before and after calibration \(page 19\).](#)

If you want to check the graph of the actually measured reverberation characteristics after MCACC calibration (not the prediction), measure the reverb characteristics again after calibration.

For details, see [Displaying the reverb characteristics after EQ calibration \(actually measured values\) \(page 20\).](#)


- If calibration is performed with the Full Auto MCACC's EQ Type set to anything other than SYMMETRY (to either ALL CH ADJ or FRONT ALIGN), the reverberation characteristics after calibration cannot be predicted, so the graph for the characteristics after calibration ("After") cannot be displayed. In this case, the graph for the characteristics after calibration can be displayed by measuring the reverberation characteristics again with the same EQ Type as the type used for calibration. For details, see [Displaying the reverb characteristics after EQ calibration \(actually measured values\) \(page 20\).](#)

# Applications Operations

This section explains operations from calling out the measurement stored on the computer to displaying graphs and storing data. Launch MCACC Application before performing the operations below.

## Opening measurement data

### 1 Select “Open” under “File” on the menu bar.



### 2 Select the “.mcacc” file stored on the computer, then select “Open”.

The measurement data is displayed.

The “.mcacc” file is stored in the folder specified at “MCACC Data” under the AVNavigator’s “Settings” menu.

#### Note

- The data used to display the reverberation characteristics graph (Reverb), the group delay characteristics graph (Group Delay) and the MCACC parameters are not deleted even when the receiver's power is turned off. However, for the data used to display the reverberation characteristics graph (Reverb) and the group delay characteristics graph the data stored in the receiver is overwritten when the reverberations are measured again. If you wish to display graphs of various sets of data, perform the operation in AVNavigator to transfer the measurement data to the computer each time measurements are made. For details, see [Transferring measurement data from the receiver to the computer \(page 4\)](#).

Continue 


## Graph and parameter displays (names and functions of parts)

When measurement data is received, the graphs and parameters display window appears. The display window is divided into three items, "Reverb", "Group Delay" and "Parameters". Select the desired tab to switch to that window and display the respective details.


### Reverb (graph of the room's reverberation frequency characteristics)

The display can be switched between the reverb characteristics graphs before and after calibration. You can switch the display between individual displays for the different channels/frequencies or a list display of all the channels/frequencies (ALL). Below we explain the different parts of the individual displays and the ALL display, using the channel display as an example.

#### Individual display (Example: Front channel)



#### ALL display




Continue

## Group Delay (graph of the speaker's group delay characteristics)


You can switch the display between the speaker's group delay characteristics before calibration and the speaker's group delay characteristics after calibration. You can also switch between the group delay characteristics for all channels and the group delay characteristics for individual channels.

These graphs are only displayed for receivers supporting the Full Band Phase Control function.



## MCACC Parameters (list display of MCACC parameters)

A list of the measurements in all the MCACC memories is displayed. It is also possible to display the measurements in the individual MCACC memories.



(Depending on the model, the values at "Speaker Distance" may be displayed in feet (ft).)

Continue

## Application Operations (Continued)

### 1 Menu bar and menu icons

You can choose the following commands from the application menus.

File	
 <b>Open</b>	Calls out measurement data and files stored on the computer. (see <a href="#">page 6</a> and <a href="#">page 13</a> ). <sup>a</sup>
<b>Close</b>	Closes a file.
 <b>Save</b>	
<b>Save As</b>	Save measurement data in a file (see <a href="#">page 12</a> ). <sup>a</sup>
 <b>Receive</b>	With this application, “Receive” cannot be used.
 <b>Print</b>	Prints the current individual graph. <sup>b</sup>
 <b>Preview</b>	Displays a preview screen to show how the printed page will appear. <sup>b</sup>
<b>Exit</b>	Exits the application.

- a. Choose “Save As” if you wish to save already saved data with a different name.
- b. It is not possible to print or preview items that have not been received (items for which there is no data).

Display	
<b>Graph</b>	The way in which the graphs are displayed can be changed. Graph 2D <b>2D</b> : Displayed in two dimensions. Graph 3D <b>3D</b> : Displayed in three dimensions.
<b>Type (Reverb display only)</b>	The reverb characteristics graph display type can be changed. Each Ch: All the channels are displayed individually. The “Each Ch” display type is set when EQ calibration is performed with the reverberation type set to “ALL CH ADJ”. Pair Ch: Composite reverb characteristics for the left and right pairs of the “Front”, “Surround” and “Surr Back” channels are displayed. The “Pair Ch” display type is set when EQ calibration is performed with the reverberation type set to “SYMMETRY” or “FRONT ALIGN”.
<b>Demo</b>	Displays 3D graphs with rotating. <sup>a</sup>

- a. To finish, reselect and uncheck the box.

Continue 

<b>Window</b>	
 <b>Cascade</b>	Cascades files. <sup>a</sup>
 <b>Tile</b>	Tiles files. <sup>a</sup>
<b>Minimize</b>	Minimizes the window.
 <b>Arrange</b>	Arranges minimized icons. <sup>a</sup>

a. Available when two or more files are open.

<b>Help</b>	
<b>Glossary</b>	Displays definitions of terms related to the MCACC function and this application.
<b>Version Info</b>	Displays the version of the application.

**2 Display item selection tab**

A graph for the selected item or the MCACC parameter list is displayed.

**3 Level [dB]**

The level axis.

**4 Time [msec]**

The time axis.

**5 Channel memo (only available when the channels are displayed on the reverberation characteristics graph)**

Allows you to record a short memo about each channel.

**6 Date and time**

Display the date (yyyy.mm.dd) and time when the measurement data was transferred to the PC.

**7 Before and After selection buttons**

Select "Before" to display the graph of the characteristics before calibration, "After" to display the characteristics after calibration.

**8 Channel and frequency switch buttons**

**Ch:** Selects channel display mode (frequencies are displayed along graph depth axes).

**Freq:** Selects frequency display mode (channels are displayed along graph depth axes).

**9 All/individual display switch menu**

Allows you to select All display or individual display (Left, Center, etc.).

**10 Graph adjustment bar**

**Z:** Increases or reduces the display unit for the graph's vertical axis scale (Level [dB] or Group Delay [msec]).

**M:** Moves the display position of the graph's vertical axis scale (Level [dB] or Group Delay [msec]).


**E:** Moves the viewpoint of 3D graphs vertically. (Cannot be changed for 2D graphs.)

**R:** Moves the viewpoint of 3D graphs horizontally. (Cannot be changed for 2D graphs.)

**Continue**

### 11 Bar Graph

Changes the type of graph display. The display switches between the band graph and bar graph by pressing this button.



**Reverb:**  
Move the time axis.  
**Group Delay:**  
Move the frequency axis.

### 12 File memo

Memos concerning the file (conditions at the time of measurement, etc.) can be stored for the different items.

### 13 Reverb type

Indicates whether the reverb characteristics are before calibration (EQ OFF) or after calibration (EQ ON). (For the reverb characteristics after calibration, the EQ calibration curve name is displayed.)

### 14 Legend

Shows which colors in the graphs correspond to which channels or frequencies.

When the speaker's group delay characteristics graph is displayed, the following channels are indicated (maximum): **F**: Front, **FH**: Front height or **FW**: Front wide, **C**: Center, **S**: Surround, **SB**: Surround back

### 15 Freq [Hz]/Channel

In channel display mode, it becomes the frequency axis. In frequency display mode, it becomes the channel axis.

### 16 Group Delay [msec]

This axis indicates the group delay amount (length of group delay time).

### 17 Freq [Hz]

This is the frequency axis.

### 18 Channel

This is the channel axis.

### 19 List display/individual display selector buttons

All the MCACC memories are displayed when "ALL Memory" is selected, individual MCACC memories are displayed when set for individual displays ("Memory1", etc.).


**Continue** 

## Saving graphs in data files

The measurement data transferred from the receiver to the computer is stored in a file with the “.mcacc” format. This “.mcacc” file can be saved in CSV format (with the extension “.csv”) or text format (with the extension “.txt”).

### 1 To save measure data, choose “Save” from the “File” menu.

If you have data that has already been saved and want to save it under a new name, choose “Save As”.



### 2 Check the save location, assign a file name, then click “Save”.

#### Note


The CSV or TXT format file is often used to transfer data to applications such as databases and spreadsheets. You can use these applications to view the numeric values in your measurement data. However, if you use another application to edit the data and then save the file, the Advanced MCACC application may be unable to open the file.

**Continue**

## **Opening data files**

You can open and display two or more data files to compare the data in the files.

- 1 Select “Open” from the “File” menu in the menu bar.**



- 2 Select a file to display and click “Open”.**

The previously saved measurement data is displayed.

## **Exiting the application**

- 1 Select “Exit” from the “File” menu.**



The application closes.

# How to Interpret the Graphs


As indicated in [Things you can accomplish with this application \(page 3\)](#), the reverb characteristics graph can be used as reference when determining the calibration time position with the receiver's "Advanced EQ Setup" function. It is also a valuable means for checking the effect of measures taken to improve the acoustics of the room. The display can be switched between the reverb characteristics graphs before and after calibration. For details, see [About the display of the reverb characteristics graphs before and after calibration \(page 19\)](#).

The group delay characteristics graph can be used to check the group delay characteristics (before calibration) of the speakers being used and the effect of calibration with the Full Band Phase Control function. For details, refer to [Reading the group delay characteristics graph \(Group Delay\) on page 21](#).

## How to interpret reverb graphs (Reverb)

The graphs show changes in microphone input level along a time axis, beginning from a state of quiet at time 0, when test tones begin to be output, and continuing while a constant level of sound is output from the speakers.

- If there is absolutely no reverberation in your room, the graph will look like figure A below.
- If there is reverberation, the graph will show a gradual accumulation of acoustic power, as shown in figure B.



### Note

- Due to an effect known as "group delay", lower frequencies may take longer to be generated than higher frequencies (this is most obvious when comparing the frequencies around 0 ms).
- If a graph extends beyond the display range, or almost fills it, you can change the display by using the Z (Zoom) control on the graph adjustment bar, adjusting the display range of the Level [dB] scale so that the whole graph is visible.
- Since channel level and speaker distance settings are displayed in the graphical output, it is best to make sure these settings (made in the Auto MCACC "ALL" or "Channel Level" setup) are adjusted properly before reverb measurement.
- Even in cases where there is a great difference in the output levels of different frequencies (the frequency characteristics of the room are poor), the frequency characteristics of individual channels can be set closer to flat using the "SYMMETRY" or "ALL CH ADJ" calibration settings in the receiver's "Auto MCACC" function. (For details, see the receiver's Operating Instructions.)
- It is usually not possible to calculate the equalization values employed by the receiver's Acoustic Cal EQ function simply by viewing the graphs displayed on your PC. (This is because the automatic adjustments made by Acoustic Cal EQ function take account of factors such as equalization band interference and analytical filter characteristics, to achieve the optimum characteristic profile.)
- There may be differences on the reverb characteristics graphs after measurements with the Full Auto MCACC function as compared to after measurements with the Reverb Measurement function (Manual MCACC → "EQ Professional") due to the standing wave control setting. With Full Auto MCACC, the reverberations are measured with standing wave controlled, so the reverb characteristics graph does not reflect the influence of the standing waves. By contrast, with Reverb Measurement, the reverberations are measured without standing wave control, so you can check the reverb characteristics including the influence of the standing waves. If you want to check the acoustics of the room (with the standing waves), we recommend using Reverb Measurement.

Continue 


## Deciding the time period for Advanced EQ Setup calibration

With conventional MCACC EQ calibration, the microphone input's data acquisition time was fixed at between 80 and 160 [ms] (red part of Figure 1). By contrast, with the receiver's Advanced EQ Setup function allowing more professional equalization, the customer can select individual points between 0 and 80 [ms] (with a 20 ms width) (blue part of Figure 1).

### Note

You can specify the time period setting using the "Advanced EQ Setup" in the "EQ Professional" sub-menu (in the "Manual MCACC" menu). This setting is not required if you're satisfied with the results of the "Full Auto MCACC" setup (For details, see the receiver's Operating Instructions).

**Figure 1: Comparison of microphone data acquisition time periods**




To decide the time period for Advanced EQ Setup calibration, view the graphs of the measured reverb characteristics, and refer to the following three patterns.

### Pattern 1: Different reverb characteristics for high and low frequencies

In rooms with reverb characteristics like those shown in Figure 2, lower frequencies often seem overly reverberant compared to higher frequencies (i.e. the room sounds 'boomy'). With conventional MCACC EQ calibration, data between 80 and 160 [ms] (red part of Figure 2) was acquired, so the low frequency volume was deemed high and the high frequency volume deemed low, and the equalization curve was calibrated with the high frequencies somewhat boosted. However, for the characteristics of the sound reaching the ear directly within about 40 ms, there is enough volume that there is no real need to boost the high frequencies, so with equalization using the conventional MCACC EQ calibration the high frequencies sometimes sounded too strong. Therefore, the Acoustic Cal EQ may result in a room where high frequencies sound shrill. **In cases like this, setting the time period for Advanced EQ Setup to 30 to 50 msec (the blue area in Figure 2) to adjust for sounds coming directly from the speakers can flatten the frequency response for direct sounds (including initial reflections) and give a better-balanced sound field.**

**Figure 2**




**Continue**

## Pattern 2: Different reverb characteristics for different channels

If the reverb characteristics differ for the different channels as shown in Figure 3, equalization using the conventional Acoustic Cal EQ acquired data between 80 and 160 [ms] (red part of Figure 3), so equalization was performed to gradually equalize the tone of the different channels for 80 ms from the time the sound was emitted from the speakers and after (it was not possible to equalize the response of the direct sound). However, the sense of placement and movement of the acoustic image and the unity of the sound from the different speakers is influenced not by the reverberations but by the direct sound from the speakers (including the early reflected sound). **In cases like this, you should use Advanced EQ Setup and set the time period to 30 to 50 msec (the blue area in Figure 3). This allows the characteristics of direct sounds to be balanced for each channel, giving an ideal sound field with good acoustic positioning and movement.**


**Figure 3**



## Pattern 3: Similar reverb characteristics for high and low frequencies and all channels

As shown in Figure 4, when the reverb characteristics for all channels are similar across all frequencies, your sound experience will probably not be adversely affected by reverberation. **We recommend calibrating with a time of about 60 to 80 [ms] (green part of Figure 4) specified at Advanced EQ Setup. This produces a total calibration for both direct sounds and reverberations, resulting in an ideal sound field.**

**Figure 4**



### Note


- If you are not sure which time period to specify in Advanced EQ Setup, start by trying 30 to 50 msec. If the graphs show an unusual reverb curve for a specific frequency, the cause may be some accidental variation. Instead of selecting 30 to 50 msec, try another time period.
- Another good method is to try various time periods in Advanced EQ Setup and select the one which sounds the best.
- Time period settings cannot be made on the PC. They can only be made on the GUI screen output from the receiver's video outputs, using the receiver's Advanced EQ Setup function.

**Continue**

## Checking steps to improve your room's reverb characteristics


The reverb characteristics of your listening room graphs are evident from the graphs. For your reference, the following four examples explain how different types of rooms appear in the graphs.

### Case 1: Graph rises to right across all frequencies



This is probably a room with a good deal of reverberation. If possible, we recommend that you try installing some sound absorbent material to create a deader acoustic space according to your preference.


### Case 2: Specific channel shows unusual reverb characteristics



There is probably some object near the speaker which affects sound reproduction. If possible, we recommend that you try to reduce the influence of that object.


Continue

### Case 3: Specific frequency shows unusual reverb characteristics



There is probably something in the room that affects the reproduction of that frequency. If possible, try to find an arrangement that reduces the effect.

### Case 4: A specific channel is slow to start



This can happen when a speaker is unstable. If possible, we recommend that you try to stabilize the speaker stand, to bring the characteristics of that channel into line with the other channels.

#### Note

In all of these cases, when the "Full Auto MCACC" operation is performed, the calibration time position is selected automatically in consideration of the room's characteristics so that the optimum sound field can be achieved. (See the receiver's Operating Instructions.)

When measurements are made with the "Auto MCACC" function, automatic calibration taking the reverberations into consideration is only performed when "ALL", "Keep SP System" or "EQ Pro & S-Wave" is selected at "Auto MCACC". (See the receiver's Operating Instructions.)


Continue

## About the display of the reverb characteristics graphs before and after calibration

By comparing the reverberation characteristics graphs before and after calibration, you can check how the reverb characteristics have been calibrated. Select "Before" to display the graph of the reverberation characteristics before EQ calibration, "After" to display the graph of the reverb characteristics after EQ calibration. If you want to check the actually measured reverb characteristics after EQ calibration, see [Displaying the reverb characteristics after EQ calibration \(actually measured values\) \(page 20\)](#).


### Graph of reverb characteristics before calibration

You can see that the reverb characteristics of the various frequencies of the different channels are uneven.



### Graph of reverb characteristics after calibration

You can see that compared to the graph before calibration the lines for the individual frequencies move vertically in parallel by the amount of equalization and converge near the specified point on the time axis (30-50 ms by default).



#### Note

- The graphs displaying reverb measurements both before and after calibration are displayed in 2-D for comparison purposes.
- With Full Auto MCACC, the "After" graph can only be displayed when calibration is performed with the EQ Type set to SYMMETRY. When calibration is performed with the EQ Type set to either ALL CH ADJ or FRONT ALIGN, measure the actual reverberation characteristics again. For details, see [Displaying the reverb characteristics after EQ calibration \(actually measured values\) \(page 20\)](#).

Continue 

## About the types of displays of the graph for the reverb characteristics after EQ calibration

### For "SYMMETRY" or "FRONT ALIGN"

- The display type is set to "Pair Ch" ([page 9](#)). For reasons of the properties of the different EQ curves, when the "Each Ch" display type is set, the reverb characteristics for the different channels do not line up properly.
- The reverb characteristics prior to calibration are displayed in the "Each Ch" mode, so if you want to compare the characteristics before and after calibration, set the display type prior to calibration to "Pair Ch". This way the number of channels before and after calibration are the same, allowing you to compare.

### For "ALL CH ADJ"

- The display type is set to "Each Ch" ([page 9](#)). For reasons of the properties of the EQ curves, when the "Pair Ch" display type is set, the reverb characteristics for the different pairs of channels do not line up properly.
- Since the "Each Ch" display type is set both before and after calibration, the graphs can be compared as such.

## Displaying the reverb characteristics after EQ calibration (actually measured values)

The graphs for before and after calibration can be displayed at the screen displaying the graphs of the reverberation characteristics after Full Auto MCACC (EQ Type:SYMMETRY) measurements, but note that the graph displayed here for the characteristics after calibration is a prediction of the reverb characteristics after MCACC calibration. If you want to check the graph of the actually measured reverberation characteristics after MCACC calibration (not the prediction), you must re-measure the reverb characteristics after calibration. To do so, follow the procedure described below. If the "Full Auto MCACC" operation has never been performed, conduct the "Full Auto MCACC" operation here. (See the receiver's Operating Instructions.)

### 1 Select the "EQ Professional" option for "Manual MCACC", and perform with "Reverb Measurement" set to "EQ ON". (See the receiver's Operating Instructions.)

Measure the room's reverb characteristics after equalization with the microphone at the same position as when the "Full Auto MCACC" operation was performed. The measurements are performed with the EQ values stored in the MCACC memory selected on the receiver, so before measuring the reverb characteristics, select the MCACC memory to be measured after equalization.

### 2 After the "Full Auto MCACC" operation is completed, press the "HOME MENU" button to close the home menu.

The measurement data is prepared to be sent at the point that the home menu is closed.

### 3 Launch AVNavigator on the computer.

### 4 From the AVNavigator menu, select "Settings", then select the "MCACC Data" tab.

### 5 Specify the "MCACC Data Storage Folder".

The measurement is saved in the folder specified here. The folder in which the data is saved can be changed by pressing "Change".

### 6 From the AVNavigator menu, select "MCACC Appli" to launch MCACC Application.

When the MCACC application is launched, the "MCACC data" screen appears simultaneously.

### 7 Follow the instructions on the "MCACC data" screen to download the data measured in step 1.

The data measured in step 1 is transferred to the folder specified in step 4.

### 8 Select the ".mcacc" file stored on the computer, then select "Open".

You can display the graph of the reverberation characteristics actually measured after EQ calibration by displaying the Reverb graph and selecting "After".


Continue 

## Reading the group delay characteristics graph (Group Delay)

Group delay characteristics graphs for before and after calibration can be displayed. By comparing the two, it is possible to check in detail the group delay characteristics of the speakers being used and the effect of calibration using the Full Band Phase Control function. These graphs are only displayed for receivers supporting the Full Band Phase Control function.


### Group delay characteristics graph for before calibration

This graph lets you check that the low frequency band is delayed with respect to the high frequency band (that a group delay is occurring) for the different channels.



### Group delay characteristics graph for after calibration

This graph shows you that the delay time difference between bands has been reduced and that the group delay has been calibrated for the different channels.



#### Note

Depending on the speakers being used, the listening environment, etc., the group delay characteristics graphs may be displayed with sharp angles. With actual calibration, however, so as not to tarnish the natural sound, compensation is not performed for characteristics that rise and fall at extremely sharp angles and but instead with priority on group delay characteristics between the different speakers, so there is no adverse effect on the sound quality.

# Display of the MCACC parameters

In addition to the reverberation frequency characteristics and group delay characteristics data measured with the Advanced MCACC function, all the parameters (results of measurements) set in the MCACC memories can be checked on the computer.


## Parameters that can be displayed

1. Speaker Setting (Speaker system and crossover frequency)
2. Channel Level (Speaker output level)
3. Speaker Distance (Distance to the speaker)
4. Standing Wave Control (Standing wave control filter)
5. Acoustic Cal EQ (Calibration of the listening environment's frequency characteristics)<sup>a</sup>

a. In addition to the EQ calibration values stored in each MCACC memory, the EQ calibration curve name ("Symmetry", "All Ch Adjust" or "Front Align") is also displayed. Furthermore, "Custom" is displayed for memories for which the equalizer has been adjusted manually. Measurements of the reverb characteristics after calibration (page 20) are performed applying the EQ calibration curves for these memories.

## Displays of the different memories

It is possible to receive and display the data for all the MCACC memories (MEMORY1 to MEMORY6), but also possible to display the data for the individual memories.



(Depending on the model, the values at "Speaker Distance" may be displayed in feet (ft).)

### Note

When there are items that cannot fit on the display, move the scroll bar on the screen to display the remaining data.

## **Updating the Application**

---

You can check whether or not you need to update the MCACC Application software at “Software Update” on the AVNavigator menu.

If AVNavigator needs to be updated, download the update file and update AVNavigator.

MCACC Application is updated as necessary by updating AVNavigator.

### **1 Select “Software Update” from the AVNavigator menu.**

### **2 Click “OK” and check whether or not AVNavigator needs to be updated.**

- If “Your software is the latest version.” is displayed, updating is not needed. Select “OK” to exit.
- If “The receiver’s software needs to be updated.” is displayed, AVNavigator does not need to be updated. Select “Cancel” to exit. (To update the receiver’s software separately, follow the instructions on the screen to update.)
- If “The AVNavigator software needs to be updated.” is displayed, proceed to step 3.
- If “Both the receiver’s software and the AVNavigator software need to be updated.” is displayed, proceed to step 3.

### **3 Click “OK” to download the update file.**

Follow the instructions on the screen to update.

# Troubleshooting

---

As you use the Advanced MCACC application, errors can occur for a variety of reasons, such as incompatibilities with other applications and the current configuration of your PC. If an error occurs, refer to the troubleshooting points below.

## For European customer :

If the trouble cannot be rectified even after checking the points listed below, ask the Pioneer Service Center specified on your warranty card.

## For U.S. or Canadian customer :

If the trouble cannot be rectified even after checking the points listed below, ask the Pioneer Customer Support Division (USA) or Customer Satisfaction Department (Canada).

Pioneer Electronics Service Inc.

TEL: 800-421-1404

Pioneer Electronics of Canada, Inc.

Customer Satisfaction Department

TEL: 1-877-283-5901

## For the other country customer :

If the trouble cannot be rectified even after checking the points listed below, ask the Pioneer Authorized Distributors (See the receiver's Operating Instructions).

### The application is unstable, or does not work normally

#### Cause 1:

If your PC does not meet the requirements for using this application, the application can be unstable, very slow, or freeze up.

Check to be sure that your PC meets the requirements for using this application. (See [page 2](#).) You cannot use this application unless your PC meets all of the requirements.

#### Cause 2:

Even if the required conditions for the computer environment are met, if many files are opened in the application and all are displayed with the MCACC Parameters option, an error message may appear due to lack of computer memory.

If an error message like the one shown below appears, either close some of the opened files, or quit the application itself then restart it. If you want to compare many files, we recommend printing them out using the Print function and comparing them on paper.

Not enough storage is available to process this command.

Continue 

### AVNavigator cannot be updated

#### Cause 1:

An error message may appear if there are not enough system resources available.

Restart the computer, and with no other applications launched, launch the update file.

#### Cause 2:

Updating of Advanced MCACC may fail because of incompatibilities with other applications.


Try the following, in the order indicated.

- 1) If there are any other applications active, exit the other applications and try starting the update file again.
- 2) If that does not work, try restarting your PC, and starting the update file with no other applications active.

### Reverb characteristics graph cannot be printed

#### Cause:

It is not possible to print reverb characteristics graphs displayed in the "ALL" mode.



Print after selecting an individual channel or frequency graph.

### Some functions in application operation cannot be used

#### Cause:

You may not properly use the application software not corresponding to your receiver.

Check the model number of your receiver and use the application software corresponding to it.

Continue 

**EQ response in the graph (following calibration) does not appear flat**

**Cause 1:**

**The slope of the graph indicates the reverb characteristics. The reverb characteristics of the room itself cannot be corrected by equalization alone, so the angle of the graphs' slope is the same before and after calibration.**

Through calibration, the graphs for the different frequencies move horizontally by the amount of the equalization. For the results of calibration, you can check that the graphs line up at a specific point on the time axis.

The reverb characteristics themselves (the shape of the graph) do not change unless the listening environment is improved.

(See pages [14](#) to [16](#).)

**Cause 2:**

**For various reasons, the frequency characteristic graphs may not become flat even when equalization is performed with the "SYMMETRY" or "ALL CH ADJ" functions.**

With MCACC, calibration is performed automatically to achieve the optimum sound quality, but without any unreasonable calibration.

**Adjustments made with the "Manual MCACC" setup do not change the graph**

**Cause:**

**Despite level adjustments being made, the filters used for analysis may not display these adjustments in the graphical output.**

However, these adjustments are taken this into account by the filters dedicated to overall system calibration.

**Lower frequencies do not seem to have been calibrated for SMALL speakers**

**Cause:**

**Low frequency calibration with the equalizer is not performed for speakers that are set to "SMALL", but the reverb characteristics display shows the pure characteristics of the sound output from the speakers, so it indicates the characteristics with no low frequency calibration.**

With MCACC, optimum calibration is performed in function of the speakers' sound reproduction capacities, so there is no problem for low frequency calibration of speakers that are set to "SMALL".

**PIONEER CORPORATION**

1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

**PIONEER ELECTRONICS (USA) INC.**

P.O. BOX 1540, Long Beach, California 90801-1540, U.S.A. TEL: (800) 421-1404

**PIONEER ELECTRONICS OF CANADA, INC.**

300 Allstate Parkway, Markham, Ontario L3R 0P2, Canada TEL: 1-877-283-5901, 905-479-4411

**PIONEER EUROPE NV**

Haven 1087, Keetberglaan 1, B-9120 Melsele, Belgium TEL: 03/570.05.11

**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.**

253 Alexandra Road, #04-01, Singapore 159936 TEL: 65-6472-7555

**PIONEER ELECTRONICS AUSTRALIA PTY. LTD.**

5 Arco Lane, Heatherton, Victoria, 3202, Australia, TEL: (03) 9586-6300

**PIONEER ELECTRONICS DE MEXICO S.A. DE C.V.**

Blvd.Manuel Avila Camacho 138 10 piso Col.Lomas de Chapultepec, Mexico, D.F. 11000 TEL: 55-9178-4270

K002\_B2\_En

Published by Pioneer Corporation.

Copyright © 2011 Pioneer Corporation.

All rights reserved.